



11803 N Saguaro Blvd #14 | Fountain Hills, AZ 85268

Mixing Instructions

PRODUCT NAME: EPOXY 100

DESCRIPTION: 1A : 2B 100% Solids Flooring Epoxy

Step 1: Prep your mixing area. We recommend you mix over a tarp, spilling any chemicals can be messy and a disaster to clean off un-coated concrete or other surfaces.

Step 2: Mix one (1) part hardener to two (2) parts resin - 1A:2B. You don't have to be exact, just try and get as close to 1:2. If anything use just slightly more hardener , but not too much more or you'll significantly reduce pot life and cured physical properties.

Step 3: Cut with solvent as desired. (Acetone, Xylene, MEK, etc..)

1st Coat	20-30%
2nd Coat	10-20%
3rd Coat	15% max

note: For a very smooth surface, try to cut with as little solvent as possible on final coat.

Step 4: Stir for several minutes to ensure excellent dispersion of all chemicals

Characteristics

Pot Life:	>1hr (depends on temperature, and amount of hardener used)
Tack-Free:	8-10 hours @ 25°C (77°F)
Return to work:	~12-24hours (Spikes recommended)
Re-coat window:	do not exceed 48 hours

WARNING: NEVER APPLY TO WET CONCRETE.